

metos

DISHWASHER

DWASH 50

Installation and Operation Manual

Original Instructions



Ed. 02 - 04/2015

4246046, 4246047

SUMMARY	Page
INSTRUCTIONS	2
INSTALLER SECTION	
1. MACHINE INSTALLATION	4
1.1 Reception of the appliance	4
1.2 Water connection	4
1.3 Electrical connection	4
1.4 Temperature adjustment	5
1.5 Rinse aid dispenser operation	5
2. DETERGENT DISPENSER RETROFIT	5
2.1 Electrical connection	5
2.2 Water connection	5
2.3 Dispensing the detergent	6
3. PUMP TECHNICAL DATA AND INFORMATION	6
3.1 Washing pump	6
3.2 Emptying pump (optional)	6
3.3 Dataplate	7
USER SECTION	
4. CONTROL PANEL AND RELATIVE SYMBOLS	8
5. OPERATION	8
5.1 Cutlery and crockery loading	8
5.2 Use of detergent	9
5.3 Use of rinse aid	9
5.4 Discharge pump system (optional)	9
5.5 Compliance with hygiene regulations and H.A.C.C.P.	9
6. MAINTENANCE	10
6.1 Regular maintenance	10
6.2 Special maintenance	10
7. ALARMS	10
8. ENVIRONMENTAL FEATURES	11
8.1 Packing	11
8.2 Disposal	11
9. ECOLOGICAL FEATURES	11
9.1 Recommendations for optimal energy, water, and additive consumption	11
10. TROUBLESHOOTING	12



READ THE INSTRUCTIONS CAREFULLY BEFORE INSTALLING THE MACHINE.



WARNING: FAILURE TO COMPLY (EVEN PARTIALLY) WITH THE RULES GIVEN IN THIS MANUAL WILL INVALIDATE THE PRODUCT WARRANTY AND RELIEVES THE MANUFACTURER OF ANY RESPONSIBILITY.



INSTRUCTIONS

This instruction booklet must be kept with the dishwasher for future consultation. If the dishwasher is sold or transferred to another user, make sure the booklet always goes with the appliance so that the new owner can have the necessary information on operation and the relative instructions.

The instruction booklet must be carefully read before installation and first use of the dishwasher.

- **Adaptation of the electrical and water systems for dishwasher installation must only be carried out by qualified operators.**
- This dishwasher must only be used by adults. This is a professional machine to be used by qualified personnel, and installed and repaired exclusively by a qualified technical assistance service. The Manufacturer declines any responsibility for improper use, maintenance or repair.
- This appliance can be used by trained youth aged from 15 years and above. It cannot be used by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge.
- Children shall not play with the appliance.
- Cleaning and user maintenance shall not be made by children without supervision.
- Accompany the door in opening and closing.
- Make sure the dishwasher is not resting on the power cord or the filling and drain hoses. Level the machine by adjusting the support feet.
- Do not use the appliance or any part of it as a stepladder or means of support as it has been designed exclusively to bear the weight of the dishrack containing dishes to be washed.
- **The dishwasher is designed only and solely for washing plates, glasses and various crockery with human food type of residue. DO NOT wash articles polluted with petrol, paint, bits of steel or iron, fragile objects or material not resistant to the washing process. Do not use acidic corrosive chemical products or alkaline and solvents or chlorine based detergents.**
- Do not open the machine door when operating. In any case, the machine has a special safety device which immediately stops the unit if the door is open, thus preventing water spillage. Always switch the machine completely off and drain the water tank, before accessing inside.
- **This machine must be disconnected from the electrical supply after use at the end of the day and for any service/maintenance operation. Switch off the main switch located on the wall, which shall be installed by a professional installer. Shut the water supply valve(s).**

- The user must not carry out any repair and/or maintenance operations. In any case contact qualified personnel.
- Servicing of this dishwasher must be performed by authorized personnel.
N.B.: Only use original replacement parts. Otherwise the product warranty is invalidated and the manufacturer is no longer responsible.
- **Do not use old load pipe, but only new ones.**
- Some important rules must be followed for using this appliance:
 - 1) never touch the appliance with wet hands or feet
 - 2) never use the appliance when barefoot
 - 3) do not install the appliance in places exposed to water sprays.
- Do not dip bare hands into water containing detergent. If this should occur, wash them immediately with plenty of water.
- Only follow the instructions given in the manufacturer's booklet for cleaning operations (chap. 6).
- This appliance is designed to work at room temperatures from 5°C up to a max. 35°C, in a suitable room.
- Do not use water to extinguish fires on electrical parts.
- Do not cover the intake or dissipation grids.
- Only qualified personnel can access the control panel, when the main power switch is OFF.
- The machine has an IPX3, protection rating against accidental water splashes and is not protected against pressurized water jets. Pressure-cleaning systems shall, therefore, not be used on this machine.



ATTENTION: INTERNAL CLEANING OF THE MACHINE SHALL BE CARRIED OUT AT LEAST 10 MINUTES AFTER THE POWER SWITCH HAS BEEN TURNED OFF.



ATTENTION: DO NOT INSERT HANDS AND/OR TOUCH THE PARTS LOCATED AT THE BOTTOM OF THE WASH TANK AND/OR AT THE END OF THE WASH CYCLE.

NOTE: The manufacturer declines any responsibility for accidents to people or any damage deriving from failure to observe the above listed instructions.




table 1

ATTENTION:

At the end of installation make sure to remove the parts of this booklet relevant to the installer, for future consultation.

1. MACHINE INSTALLATION**1.1 Reception of the appliance**

After removing the packing, ensure that the appliance has not been damaged in transport. If it has, inform the retailer. If safety has been compromised, do not install the machine.

Double check the firm tightness of all hose-clamps on piping, nuts and bolts, and fasteners, that might come loose with the transport, to prevent water dripping or leakages, or other damages, during the machine's operation.

For disposal of the packing, see chap. 8.

1.2 Water connection

Water characteristics table	Min	Max
Static Pressure	200Kpa	400Kpa
Dynamic Pressure	150Kpa	350Kpa
Water hardness	2°f	8°f
Hot water-supply temperature	50°C	60°C
Capacity	10lt/min	

Connect the machine's water supply with an interrupt valve capable of quickly and completely shutting off water intake.

Make sure that the water supply pressure comes within the values given in the Table 1. If it is less than 2 bar dynamic pressure (200 kPa) an external pressure pump must be installed to guarantee optimal machine operation.

If, however, the water supply pressure is greater than 400 kPa, a pressure reducing device must be installed.

For water with average hardness greater than 8°f., a water softener **must be used**.

This will result in cleaner dishes and longer life of the appliance.

Note: All damages caused by the hydraulic limestone (calcareous water higher-up than 8°f and without watersoftner) are not covered by warranty.

In order to ensure the optimum performance, the water supply temperature must come within the range given in table 1.

Each machine is provided with a rubber tube with a 3/4" threaded attachment for water filling.

Connect the emptying tube, supplied with the appliance, to the union elbow located under the tub so that water flows freely. If it is not possible to empty the water at a level lower than the drain of the appliance, it is advisable to install an emptying pump, which can be provided by request.

The emptying tube should always be connected to a siphon to prevent odor back-up from the screen.

1.3 Electrical connection

The electrical connection must be made according to current technical standards.

Ensure that the mains voltage corresponds to the value given on the machine dataplate.

A suitable omni-polar one-way switch shall be installed and sized according to the absorption provided, in order to completely guarantee the disconnection from the supply mains, under "category III" overvoltage conditions.

This switch shall be included in the power network solely and exclusively used for this purpose and installed in the immediate vicinity of the machine. Always turn the machine off via this switch. This is the only model of switch that guarantees a total electrical power disconnection.

Make sure that the facility is equipped with efficient ground connection.





WARNING: check very carefully if the “ground connection” of the machine, is properly sized and fully efficient, and that not too many units are connected on it. An undersized or poor “ground connection” might lead to corrosion and/or pitting effect on the stainless steel plates, even to perforation.

On the back of the appliance there is a terminal marked with the symbol , which is provided for equipotential connection between different appliances (see electrical safety standards).



Feed cable: the retailer - importer - installer must ensure that the feed cable complies with the cable insulation category of the workplace, in conformity with current Technical Standards.



1.4 Temperature adjustment

If necessary, the water temperature of the wash and rinse cycles can be adjusted by means of the fine-adjustment screws on the respective thermostats.

The recommended temperatures are 55°C for the wash cycle (tub) and 85 - 90°C for the rinse cycle (boiler).

1.5 Rinse aid dispenser operation

Operation: It utilizes the difference in combined pressure caused by turning the washing pump on and off, and the rinse pressure.

Water connection:

- 1) Connect the dispenser tube fitting **A** to the pump, by means of the rubber tube installed in the appliance (pump pressure).
- 2) Connect the small black rubber tube by the brass delivery fitting **B** to the connection in the boiler (injector).
- 3) Make sure that the green product suction tube is inserted on the special fitting **C** and that the small filter and the ballast are inserted in the rinse aid tub.

Priming: To prime the dispenser, turn on the appliance and carry out several complete wash cycles.

Adjustment: With each rinse cycle, the dispenser draws an amount of rinse aid, adjustable from 0 to 4 cc, equivalent to a length of 0 to 30 cm drawn into the suction tube.

In order to regulate the dispenser to the minimum amount, turn the adjustment screw **D** completely clockwise. For the maximum amount, turn the screw anticlockwise about 20 complete turns.

For the correct amount of rinse aid, see the paragraph **5.3 Use of rinse aid**.

Note: for each turn of the screw the amount of the product drawn into the tube varies by 1.6 cm, equivalent to 0.2 cc/turn (about 0.21g/turn with a concentration of 1.05 g/cm³ of rinse aid). The rinse aid cannot function properly if the difference in level between the bottom of the machine and the container exceeds 80 cm.

THE DISPENSERS ARE PRE-SET TO A 5 CM OF TUBE (0,65 gr.) INTAKE OF PRODUCT FOLLOWING A TEST PHASE SYSTEM CHECK. THIS MEASUREMENT SHOULD BE ADJUSTED ACCORDING TO THE TYPE OF RINSE AID USED AND WATER HARDNESS.


2. 2. DETERGENT DISPENSER RETROFIT

2.1 Electrical connection

Follow the wiring diagram attached to the machine.

2.2 Water connection

- a) A Ø 12 hole must be made on the back of the appliance.
In some appliances the hole has already been made and is closed with a plastic cap. Remove the cap from the hole and fit the delivery connection.
- b) Otherwise, drill one of the same diameter as the injector on the back part of the tub (see image 3). This operation must be carried out by the Technical Service.
The hole must be made above the water level.
Important: make the hole in a position distant from the overflow tube, so that detergent does not flow out immediately. Fix the dispenser in a vertical position with tube connectors turned downwards, making sure not to place it on energized components.
Clean the inside of the machine from any drilling residual.



code 10799
image 1





image 2




- c) Correctly mount the injector **C** using the appropriate fixtures.
- d) Connect the suction tube to the suction attachment of the dispenser (see image 3 point **A**).
- e) Connect the delivery tube to the other attachment of the dispenser, and the delivery fitting (see image 3 point **B**).
- f) Insert the suction tube with filter in the detergent tub.
- g) Prime the detergent and proceed to dispense.

2.3 Dispensing the detergent

The detergent dispenser capacity can be adjusted using a screwdriver as shown in pict 2.

Every 2 cm of product drawn into the tube corresponds to 0.25 cm³ equivalent to 0.3 g (with a concentration of 1.2g/cm³). For proper dispensing see paragraph 5.2.



3. TECHNICAL DATA AND USEFUL INFORMATION ON PUMPS

3.1 Washing pump

When the dishwasher has not been used for some time, check that the washing pump turns freely.

To do this, operate using a screwdriver in the special slot on the ventilating side of the motor shaft.

In case of blocking, turn the main switch off and move the motor shaft, inserting the screwdriver in the notch, turning it clockwise and anticlockwise.

3.2 Emptying pump (optional)

How installing, pay particular attention to the position of the emptying tube (see image 4). See paragraph 5.3 for operations description.










image 4




3.3 Dataplate

							
Code DWXXXX.YYYY		CL/Part					
Model DESCRIPTION							
S/N DWXXXXXXX		Type					
A	400V 3N 50HZ	8A	ANNO PROD.: 2013				
B	3500W	500W					
C	IPX3	16A					
Pressione Dinamica alimentazione idrica		200-500 kPa					
Pression dynamique arriv��e d'eau							
Dynamic pressure water supply							
Dynamischer Druck asserreinlauf							
		MADE IN ITALY					
Pressione dinamica vapore saturo		kcal					
Pression dynamique vapeur satue���							
Dynamischer Druck gesattigter Dampf							
Pression Dinamica Vapor Saturado							
		Temperatura massima acqua in ingresso					
		Temperature max eau a l'entre					
		Maximale Temperatur Wasseranschl					
		Maximum Water temperature in-feeding					
Model		S/N					



- A Power supply
- B Total power
- C Protection rate
- D Total absorption
- E Pump power
- F Electrical protection rate
- G Dynamic Pressure





4. CONTROL PANEL AND RELATIVE SYMBOLS

CONTROLS

1		Main switch 0-1
2	START	Cycle START button
3		Manual empty button (optional)

INDICATORS

a		Washing cycle indicator
b		Temperature indicator



5. OPERATION

- Check that the filter is correctly fitted in its seat (image 5-6). The filter must be cleaned after every 20 wash cycles and whenever necessary. **DO NOT use the appliance without the filter.**
- Insert the overflow tube in the special seat inside the tub (image 5-6).
- Close the dishwasher door.
- Insert the special rinse aid dispenser tube in the liquid container and check that the quantity of additive is sufficient for daily use (see paragraph. **5.3 Use of rinse aid**).
- Open the water tap and plug in the main switch.
- Turn switch 0-1 (**1** - see chap. **4**) to position 1 (pressed). The cam of the switch turns orange (see chap. **4**). The machine will automatically fill the tub with water; then the heating phase begins. Indicator **b** (see chap. **4**) comes on when the water temperature is reached.
- Insert the rack filled with dishes to wash. The plates must be correctly placed in the rack (see image 8).
- Before starting the wash-cycle, in absence of an automatic dosing system, pour the detergent in the wash-tub. When the temperature indicator **b** will turn on, press the **2 START** (see chapter **4**) for at least a second. The beginning of the cycle is indicated either by the light on the button itself or on the **a** lamp. At the end of the washing cycle, a hot rinse cycle will take place. the **a** lamp (see chap. **4**) will turn off when the cycle has finished. **Note:** At cycle end with the door closed, dishes do not get dried. Take out the rack or keep the door open to allow the evaporation and the drying of the dishes.
- The appliance is now ready for a new wash.
- At the end of the day, clean the machine (see chap. **6 Maintenance**).
- Turn off the machine and the water tap.
- Turn off the main wall switch.

5.1 Cutlery and crockery loading

Before cutlery and crockery loading in the machine, coarsely clean them from the leftover food.

It isn't necessary to rinse the cutlery and crockery under water.

ATTENTION: Do not wash articles polluted with petrol, paint, chips of steel or iron, ash, sand, wax, lubricant grease. These substances damage the machine. Do not wash fragile objects or material not resistant to the washing process.

Note the following recommendations:

- Crockery and cutlery should not be inserted inside one another, covering each other.
- Place the crockery in order to all surfaces can be reached by water; otherwise the dishes are not washed.
- Make sure all the crockery are in a stable position and that the hollow containers don't overturn (cups, glasses, bowls, etc.).
- Place in the rack all the hollow containers such as cups, glass, etc. **upside-down**.
- Place the crockery with deep hollow with upper face downwards, so that water can flow out.
- Make sure the smaller crockery do not fall from the rack.
- Check all the wash arms runs freely and they are not blocked by too tall or too prominent crockery. Eventually, run a manual rotation of the arms to check it.




image 5




image 6




image 7




image 8

Some foods, such as carrots, tomatoes, and others, may contain some natural dyes substances, that in large amounts, can alter the crockery and plastic parts colors. Any discoloration does not mean that the plastic is not heat resistant.

Crockery and cutlery not suitable for dishwasher

Not suitable for dishwasher:

- Wooden crockery and cutlery or with wooden parts; water at high temperature causes deformation to wood. Also the adhesives used are not suitable for treatment in the dishwasher; a consequence could be the handles detachment.
- Crafts, precious vases or decorated glasses.
- Not heat-resistant plastic crockery.
- Copper, brass, pewter or aluminum objects: they may become discolored or opaque.
- The decorations on glass, after a certain number of washes, can lose gloss.
- Fragile glasses or crystal items, if often washed, can become opaque.

We recommend to buy exclusively crockery and cutlery suitable for dishwashing.

After several washes, the glass can become opaque.

It is mandatory to repeat the washing cycle if at the end of the cycle the crockery are not well clean or if there are washing residues (glasses, cups, bowls, etc. with liquid inside).

5.2 Use of detergent

The detergent shall be the NO FOAM type, suitable for industrial dishwashers.

It is advisable to use liquid detergents.

Put the detergent directly in the tub.

The correct amount will be suggested by the product manufacturer according to the water hardness.

1cm. of the product drawn into the tube is equal to about 0.15 g. A correct amount of detergent is very important for a successful wash.

5.3 Use of rinse aid

The machine is equipped with a rinse aid dispenser.

The machine automatically draws the product.

The rinse-aid chemical, shall be suitable for professional glass and dishwashers. It is advisable to rely on specialized retailers in the sector.

5.4 Discharge pump system (optional)

To drain completely the wash-tub keep the machine ON, extract the overflow pipe and shut the door. Press the button **3** (see chap. 4) for at least a second: the discharge pump will automatically drain the wash-tub.

When the drain is completed, turn the machine OFF.


Turn the machine OFF and, after 5 seconds, ON - button **1** (see chap. 4) to fill the wash-tub and run a new cycle.

Opening the door will stop the machine that will re-start when the door is shut.

During the wash-rinse cycle the water in excess is automatically drained.

5.5 Compliance with hygiene regulations and H.A.C.C.P.

- The machines are equipped with a temperature indicator **b** - chap. 4 - which lights up when the boiler and the tub have reached the preset temperature (values set by the manufacturer). It is recommended to wait for this light to go on before starting the next cycle.
- Scrape food from the dishes carefully in order not to clog the filters, nozzles and pipes.
- Unload the wash tub and clean the filters at least twice a day.
- Check that the amount of detergent and rinse aid dispensed is correct (as suggested by the supplier of the product). In the morning before starting up the machine, check that there is enough product in the containers for daily use.
- Always clean the support floor of the dishes.
- Remove the rack from the dishwasher with clean hands or gloves so as not to dirty the cutlery.
- Do not dry or polish the dishes with non-sterilized cloths, brushes, or dusters.





6. MAINTENANCE

6.1 Regular Maintenance

WARNING: The machine is not protected against water jets, therefore do not use pressure cleaning systems.

Contact your cleaning products retailer for detailed instructions on the methods and products to use for periodic sanitizing of your appliance.

DO NOT use bleach or chlorine-based detergents for cleaning the appliance.

In order to ensure perfect performance, the appliance must be completely cleaned at least once a day in the following way:

- Turn the switch to 0 (1 - see chap. 4).
- Switch off the main switch.
- Turn off the water tap.
- Remove the overflow tube to empty the water.

For appliances provided with emptying pump follow the indications as described on paragraph 5.4.

- Remove the filter and clean it with a brush under running water.
- Remove the rotors by loosening the fixing screws, and thoroughly clean the nozzles and cleaning and rinsing arms under running water.
- Reassemble all parts and refit the rotors in their seats, fixing them with the relative screws. Take extreme care to re-assemble the nozzles in the right position (open and / or closed nozzles) and that the arms are installed with the right axial angle.
- Clean the tub thoroughly using specific products.



- At the end of the day, it is advisable to leave the dishwasher door open.

Note.: It is advisable to replace the tub water by refilling the tub at least every 20 wash cycles, or twice a day. Do not use metal brushes or corrosive products which can damage the machine.



6.2 Special Maintenance

Once or twice a year have a qualified technician inspect the machine:

- 1 To clean the electrovalve filter
- 2 To remove residual deposits
- 3 To check the watertight of the seals for water loading and unloading connections
- 4 The condition and/or wear of the components
- 5 The operation of the dispensers.



7. ALARMS

TYPE OF ALARM	CAUSE	REMEDIES
Flashing of the cycle lamp	Missed refill of water in the wash-tub	Verify the full opening of the water inlet valve or the right positioning of the overflow pipe. Switch the machine OFF and ON to reset the alarm
	Missed heating of the water boiler (in machines equipped with Thermostop)	Boiler thermostat or boiler heating element out of order. Check them or call for Service



8. ENVIRONMENTAL FEATURES

8.1 Packing

The packing consists of the following:

- A wood pallet
- A nylon bag (LDPE)
- Multi-layered cardboard
- Polyurethane foam (PS)
- Polypropylene support (PP).

We kindly advise you to dispose of the above-mentioned material in accordance with current environmental regulations.

8.2 Disposal



The use of the WEEE Symbol indicates that this product may not be treated as household waste. By ensuring this product is disposed of correctly, you will help protect the environment. For more detailed information about the recycling of this product, please contact your local authority, your household waste disposal service provider or the shop where you purchased the product.

For the disposal of the machine or one part of its, please follow the directives 2011/65/UE, 2012/19/UE and following changes and/or the legislative decrees of application.

This product or parts of it cannot be disposed of as domestic waste but must be treated by means of separate collection (see barred waste container symbol on product).

At the time of product disposal, the user must refer to the specific waste collection systems for electric and electronic appliances (WEEE).

The manufacturer guarantees the absence of dangerous substances in the EEE's used in compliance with the 2011/65/UE Directive.

In the case of failure to comply with that prescribed, the user will be subject to the sanctions envisioned by the individual European Community member.

Disconnect the machine from the electrical and water supply before disposal.

Cut off the electrical cable in order to make any other use impossible.

All the metal parts are recyclable as they are in stainless steel.

Recyclable plastic parts are marked with the symbol of the plastic material.



9. ECOLOGICAL FEATURES

9.1 Recommendations for optimal energy, water, and additive consumption

If possible operate the machine at full capacity: Thus avoiding a waste in detergent, rinse aid, and electrical and water consumption.

Detergents and rinse aids: Out of respect for the environment, use detergents and rinse aids with the highest biodegradability. Check the correct amount according to the water hardness at least once a year. An excessive amount of the product will pollute rivers and seas, an inadequate quantity will preclude proper washing and/or cleanliness of the dishes.

Temperature of the tub and boiler: The temperature of the tub and boiler are set by the manufacturer in such a way as to ensure the best washing results from the majority of detergents on the market. These may be re-set by the installer according to your detergent (see par. 1.4).

Removal of food: Carefully scrape food from the dishes using lukewarm water in moderation to help in the removal of animal fat. To successfully remove caked on material, soaking in hot water is recommended.

Note: Wash dishes as soon as possible to prevent hardening of the deposits and compromising the effectiveness of the washing.

For an effective washing process, regular cleaning and maintenance of the dishwasher is recommended (see chap. 6).

Non-compliance with the above recommendations or with any and all information within the manual could result in a waste of energy, water, and detergent, further causing an increase in user costs and/or a reduction in performance.



10. TROUBLESHOOTING

Type of Problem	Possible Causes	Cure
The appliance does not start	The main switch is turned off	Turn on the switch
The appliance does not draw water	The water tap is closed	Open the water tap
	The rinsing arm nozzles or the electrovalve filter are clogged and/or caked with lime deposits	Clean the rinsing arm nozzles, the pipes and the electrovalve filter.
	Faulty pressure switch	Replace the pressure switch (call the Technical Assistance service)
Flashing of the cycle lamp	See chapter 7 Alarms	
Unsatisfactory washing results	The washing nozzles are clogged or the washing arms do not rotate	Unscrew and clean the nozzles and the rotating column, refit them correctly in their seats
	Unremoved grease or starch	Detergent concentration too low
	The filter is too dirty	Remove the filter, clean it with a brush under running water and refit in its seat
	Check the tub temperature (it must be between 50°C and 60°C)	Adjust the thermostat or check correct heating element operation
	Length of washing cycle inadequate for type of grime build-up	Choose a longer cycle if possible, otherwise repeat wash cycle
	Wash water too dirty	Empty water from the tub, clean filters; refill the tub and correctly reposition the filters
Presence of foam	Use of unsuitable products	Use non-foaming detergent or use less of same detergent
	Tank temperature too low	Adjust the thermostat or check correct heating element operation
Glasses or dishes are not completely dry	Insufficient rinse aid	Increase the amount of rinse aid by turning the screw on the dispenser (see paragraph Rinse aid dispenser)
	The rack is unsuitable for the glasses and dishes	Use a suitable rack enabling the dishes to be tilted so water can run off
	Dishes have been too long in the machine	As soon as the wash cycle is finished, pull the rack out immediately, allowing the air to dry the glasses and dishes more quickly
	Rinse water temperature is less than 75°C - 80°C	Check the temperature of the boiler thermostat
	Surface of dishes and glasses too rough or porous for material wear	Replace type of dishes and glasses used
Streaks and spots on glasses and dishes	Too much rinse aid	Decrease the amount of rinse aid by turning the fine-adjustment screw on the dispenser (see paragraph Rinse aid dispenser)
	The water is too hard	Check the water hardness. Water should not be harder than 8°f
The appliance suddenly stops during the cycle	The appliance is connected to an overloaded circuit	Connect the appliance separately (call the Technical Assistance service)
	A safety device has been activated	Check safety devices (call the Technical Assistance service)

Type of Problem	Possible Causes	Cure
During wash cycle the machine stops and draws water	Water from the previous day has not been replaced	Empty the tub and refill it
	The tub water temperature is too high	Have the Technical Assistance service check the thermostat and the pressure switch
	Faulty pressure switch	
	The overflow tube is incorrectly positioned	Remove the overflow tube and correctly reposition it
The washing pump doesn't work	The pump is blocked	Call the Technical Assistance service

N.B. For any other problems, contact the Technical Assistance service.
The manufacturer reserves the right to alter the technical characteristics without prior notice.



Metos Oy Ab

Ahjonkaarre, FI-04220 Kerava, Finland

tel. +358 204 3913

www.metos.com